



Simply Better Connections

ATEN VanCryst™

Video Matrix Control App

User Manual

Contents

Contents	2
Overview	3
Requirements	3
Installing the App.	3
Supported Video Matrix Switch	4
Main Page	5
Logging into the Video Matrix Switch	6
Logging into the Video Matrix Switch via Scan the Network	7
Logging into the Video Matrix Switch via Select from History	11
Logging into the Video Matrix Switch via Specify a Device	13
Profile Tab	15
Control Tab	17
Switching the Video Inputs for the Video Output	19
Audio Tab	21
VM1600 & VM3200-VM3250.	21
VM51616H	22
Specifying the Audio Inputs for the Digital and Analog Outputs ..	24
Settings Tab	27

Overview

The Video Matrix Control App is a free mobile app that allows you to switch profiles, audio inputs and video inputs, and also reminds you when any new firmware is available, all through a local area network to which the target Video Matrix Switch is connected. This mobile application is especially useful for profile and AV source switching when you do not have access to the Video Matrix Switch's front panel or the web interface.

Requirements

- ♦ The Video Matrix Control App supports the following operating systems:

Mobile Operating System	Supported Version
iOS	12.0 or later
Android	8.0 or later

- ♦ Make sure to connect the mobile device to the network where your Video Matrix Switch is installed.

Installing the App

To install the Video Matrix Control App on a mobile device, do the following:

1. From the mobile device, tap the **App Store**  or **Google Play**  icon.
2. In the search box, type "Video Matrix Control App".
3. Tap **Video Matrix Control App** and then download and install the app.
4. Tap the app icon.
5. Follow the on-screen instructions to connect to the target Video Matrix Switch by scanning the network, selecting from connection history, or specifying the device IP address and password.

Note:

- ♦ The Video Matrix Control App is designed to control one Video Matrix Switch device at a time.
- ♦ If you cannot find the Video Matrix Switch, make sure that the Video Matrix Switch is connected to LAN and that the app is connected to the same LAN and then try again.

Or, scan the QR Code below to install the app.



6. From the mobile device, tap the **Video Matrix Control App** icon  .


Supported Video Matrix Switch

Model	Reference Page
VM1600A	See <i>Profile Tab</i> , page 15.
VM3200-VM3250	See <i>Profile Tab</i> , page 15.
VM51616H	See <i>Profile Tab</i> , page 15.

Main Page

When logged in, the Video Matrix Control App defaults to the scanning page. Refer to the table below for an overview of the functions on each tab.

Note: The example used in the snapshots below is VM1600A.




No.	Component	Description
1	Scan the Network	Tap to log in to a Video Matrix Switch by scanning the device in your network.
2	Select from History	Tap to log in to a Video Matrix Switch by selecting a device in the history list.
3	Specify a Device	Tap to log in to a Video Matrix Switch by specifying a device.

Logging into the Video Matrix Switch

There are three ways to log into the Video Matrix Switch on Video Matrix Control App.

- ♦ Scan the Network – see *Logging into the Video Matrix Switch via Scan the Network*, page 7.
- ♦ Select from History – see *Logging into the Video Matrix Switch via Specify a Device*, page 13.
- ♦ Specify a Device – see *Logging into the Video Matrix Switch via Specify a Device*, page 13.


The below welcome page appears when the app is opened, and each log in methods are described below.




Logging into the Video Matrix Switch via Scan the Network

To log in a Video Matrix Switch by scanning the network, do the following:

1. Open the Video Matrix Control App, wait for the welcome page to appear, and tap **Scan the Network**.




2. Wait for the scanning to finish.




3. The Video Matrix Switch and its IP address will show in the Device List.


Note: The example used in the snapshot below is VM1600A.



4. Tap **Connect** to log into the Video Matrix Switch.




5. Enter the username and password, and then tap **Connect**.



The screenshot shows the 'VM Device' screen in the ATEN Video Presentation Control App. At the top, the status bar shows the time 1:18 and signal strength. The app header is dark blue with a back arrow and the text 'VM Device'. The main content area is white and displays the device name 'VM1600A' and its IP address '192.168.1.7'. Below this, there are three input fields: 'IP address' with the value '192.168.1.7', 'Username' with the value 'administrator', and 'Password' which is currently empty. A red rectangular box highlights the 'Connect' button at the bottom of the form.


6. Now you have successfully logged into the Video Matrix Switch.




Logging into the Video Matrix Switch via Select from History

To log in a Video Matrix Switch by selecting from the history, do the following:


1. Open the Video Matrix Control App, wait for the welcome page to appear, and tap **Select from the History**.



2. The Video Matrix Switch and its IP address will show in the history list, and tap **Connect**.



3. The pre-entered device's IP address, username, and password are remembered by the Video Matrix Control App. Simply tap Connect to log in, or tap on the ID address, username, and password to edit if its required.




4. Now you have successfully logged into the Video Matrix Switch.

Logging into the Video Matrix Switch via Specify a Device

To log in a Video Matrix Switch by specifying a device, do the following:

1. Open the Video Matrix Control App, wait for the welcome page to appear, and tap **Specify a Device**.



2. Enter the device's IP address, username, and password, and then tap **Connect**.

2:28 Specify a Device

IP address
192.168.1.7

Username
administrator

Password


Connect

Back


3. Now you have successfully logged into the Video Matrix Switch.

Profile Tab

Once you have successfully logged into a Video Matrix Switch, the profile tab snapshot below appears. In the **Profile** tab, you can switch profiles for display or change the video input for the profile that is playing.




Each functions are described in the table below.

No.	Component	Description
1	Edit 	Edits the current 4 x 4 video wall layout.
2	OSD 	Tap to enable or disable the OSD.
3	Zone Selection 	Tap to select from ZoneA ~ ZoneD.
4	Audio 	Tap to mute or unmute all displays.
5	Video 	Tap to enable or disable all video outputs.
6	4 x 4 Video Wall Layout 	Tap to apply the selected pre-configured video wall layout to all displays. Note: ◆ The Video Matrix Control App can not be used to create profiles. Before using the app, make sure to create the profiles you need via the web interface. For details, see the Video Matrix Switch's individual user manual. ◆ Any configuration change made to a profile via Video Matrix Control App is only effective while the profile is being played and will not be saved to the Video Matrix Switch.
7	Profiles	Display the available pre-configured profiles for your 4 x 4 video wall.
8	Configuration Tab	Tap to make configuration to Profile, Control, Audio, and Settings tabs.

Control Tab

In the **Control** tab, you can instantly switch video inputs for each of the output.




Each functions are described in the table below.

No.	Component	Description
1	OSD 	Tap to enable or disable the OSD.
2	Input Ports	Tap to select a video input port for the video output port.
3	Output Ports	Tap to select a video output port for the video input port.
4	Configuration Tab	Tap to make configuration to Profile, Control, Audio, and Settings tabs.


Switching the Video Inputs for the Video Output

To switch a video input for a designated video wall output ports, do the following:


1. Tap Input Ports to select a video input. The selected video input port number will be shown in the apply section.



2. Select a video output or a video output group for the video input. The selected video output or video output group port number will be shown in the apply section, and then tap **Apply**.



3. Now the video inputs and video outputs are switched.




Audio Tab


In the **Audio** tab, you can specify the audio input for the digital and analog outputs of the Video Matrix Switch.

Note: The fields available in this tab may vary for the connected devices.

VM1600 & VM3200-VM3250




VM51616H



A warning message appears when you tap the Audio tab from the Video Matrix Control App.

Note: This warning message only appears on the Video Matrix Control when the connected device is VM51616H.




Each functions are described in the table below.

No.	Component	Description
1	OSD 	Tap to enable or disable the OSD.
2	Audio Output Ports	Shows the available audio output ports and tap to specify the audio input for the digital and analog outputs for the Video Matrix Switch.
3	Configuration Tab	Tap to make configuration to Profile, Control, Audio, and Settings tabs.


Specifying the Audio Inputs for the Digital and Analog Outputs

To specify an audio input for the digital and analog outputs, do the following:


1. Tap the selected audio output port number's **Digital Port**.




2. Select an option for digital port, then tap **Select**.




3. Now the digital output is muted.



4. Select an option for the analog port.




5. Now the audio input is specified to the digital and analog outputs.



Settings Tab

In the **Settings** tab, you can look up notification for system firmware updates, the current app version, and technical support contact, or log out of the app.



© Copyright 2021 ATEN® International Co., Ltd.
Released: 2021-03-30

ATEN and the ATEN logo are registered trademarks of ATEN International Co., Ltd. All rights reserved.
All other brand names and trademarks are the registered property of their respective owners.